

Cold Start Spark Plug Installation Instructions

- 1. Remove stock wire from the spark plug**
- 2. Remove the spark plug from the engine**
- 3. (This Step for Rhino's only) Screw small metal cap (included) onto spark plug**
- 4. (This Step for Rhino's only) Reinstall spark plug**
- 5. Cut stock spark plug wire about 2" from coil**
- 6. Push new spark plug wire onto the spark plug**
- 7. Cut new spark plug wire according to length as need to meet wire coming from coil.**
- 8. Do NOT cut new plug wire closer than 2" to the thick part which is the capacitor section of the wire.**
- 9. Remove new plug wire from plug.**
- 10. Slice included piece of heat shrink over cut end of the new plug wire.**
- 11. Get the included hard plastic tube which has a screw inside each end.**
- 12. Screw the plastic tube onto the plug wire that is still attached to the coil**
- 13. Screw the new plug wire into the other end of the tube.**
- 14. Slide heat shrink over the tube and use a heat source such as a heat gun or lighter to shrink it around the tube and wires.**
- 15. Push the plug wire back onto the spark plug**
- 16. Using the included self tapping screw the ground wire to a piece of metal somewhere on the vehicle which grounds the wire.**