

*Prowler Under Dash Stereo Mount:*

Qty.	Item
6	1/4" x 5/8" Screw
6	1/4" Locknut
6	7/8" Flat Washer
1	Under Dash Mount

1. Take the mounting bracket and hold it under the center of the dash of the Prowler so that the mounting holes align along the curved sections of the bottom of the dash where the 12v outlets are.
2. The mount should fit against the firewall in the rear
3. Hold the mount back in the position
4. Using a drill and a 1/4" drill bit, drill the holes thru the plastic right thru the mounting holes in the mount.
5. Start in one of the holes that go thru the firewall
6. Once first hole is drill go ahead and put a screw thru and attach the flat washer and lock nut on the backside of the firewall.
7. Continue drilling the holes and move to one of the top holes and insert screw thru that hole
8. Continue drilling and installing screws until finished
9. Now once all the screws are installed tighten them up
10. Now install the enclosure according to the instructions with it