

*Rhino Summershield Instructions***HARDWARE LIST:**

QTY.	ITEM
2	Angle Supports
1	Summershield
6	1 3/4" Rubberized Clamps
10	Rubber Grommets
10	1/4" x 1" screws
10	1/4" Lock Nuts
16	1/4" Flat Washers

**WARNING: Do not over tighten the screws holding the windshield on; only tighten enough to take the slack out. Over tightening will cause you to crack the windshield.**

Install windshield with an additional person!!!

1. Remove protective covering off windshield
2. Take the **(10) rubber grommets** and push them into the **7/16" holes** using your fingers to push them in
3. Install the bottom two clamps in the bottom two holes, **using (1) 1" screw, (2) washers, (1) Clamp and (1) 1/4" Lock nut** for each of the bottom holes.
4. Start with a **1" screw** and push it thru one end of the angle then the bottom rubber grommet on either side, slide a washer on the bolt from the inside, push bolt thru clamp and then the **1/4" lock nut**. Repeat on other side. See Fig. #1
5. For the two holes in the center use one of the **1" screws**, push it thru the angle, windshield and put a flat washer and lock nut on the inside. Repeat for the other one.
6. Repeat the same sequence for the top angle.
7. The sequence for installation of the middle two clamps are, **screw, washer, thru grommet, washer, clamp and then lock washer**. See Fig. #2
8. Repeat the same for the middle two clamps.

**Cleaning instructions:**

Clean with anything you would clean glass with such as Windex and a paper towel.



Fig. #1



Fig. #2