



3 Cardinal Court #592  
Hilton Head, SC 29926  
843-689-6500 Office  
843-689-6552 Fax

Our Website: [www.DecorativeConcreteUS.com](http://www.DecorativeConcreteUS.com)

## Project Installation, Descriptions and Procedures. Attachment # A-Remove & Replace New Concrete

New Concrete - Form, Pour, Stamp, Color & Seal: (approx 7-10 days) by DCDI

1. Remove, by jackhammer, Bobcat, and dumpster service existing concrete if necessary.
2. If removing concrete DCDI will call Palmetto Utility Protection Services (PUPS) 888-721-7877. They will notify Water, Telephone, Electric, Gas & Cable. Note we are not responsible for irrigation, and electrical to driveway lights and landscape lights.
3. Layout area with stakes/paint (according to plans if available) for customer approval.
4. Rough grade provided by others to within a 2" tolerance and we then hand grade.
5. Form the area to be poured with 1x4's for a 4" pour.
6. Set and level all forms to provide water runoff, min 1/8" per foot, but preferably 1/4" per ft.
7. Compact ground if necessary, also wet the sub surface.
8. Pour 4000 psi concrete with fiberglass for help in resisting cracks and additional strength.
9. Depending on the sun, wind the setting up process varies and timing is critical.
10. If Broom Finish skip steps 11-19.
11. Apply color hardener of your choice. This hardens the surface to over 5000 psi.
12. Using a colored release agent spread evenly over surface, prepare for stamping
13. Edge the concrete with edging tool selected by the customer for the look desired
14. Stamp the concrete using stamps selected by customer.
15. The next day, rub brick the expansion joints, edges, and general clean up of overlay.
16. Pressure wash entire job, wait until dry.
17. Hand rub with a stone all rough edges, prepare for accent color.
18. Apply accent color, wait until dry.
19. Apply first of two part sealer, (wait until dry), then apply the second.
20. Have customer sign off completed job.

Notes to customer:

1. **PERMITS:** You are responsible for all permits Town and Plantation ARB's. We can offer some help in this area.
2. **IRRIGATION:** We will do our best to protect sprinkler heads. We ask that you run the irrigation so our men can mark the heads. But, bear in mind we have no idea of how your irrigation was laid out and we sometimes drive 18" stakes into the ground, and can hit the pipes delivering water to the sprinkler heads.. Therefore you should contact your irrigation company to work with us and make sure all is OK before we pour. This is also a good time for you and your landscaper to plan pipes under the concrete for future needs.
3. **LANDSCAPING:** We are not landscapers, but will take care to protect shrubs and plants. But since we operate bobcats, jack hammers, shovels, axes, and men needing to work from the edge of your patio, pool deck, driveway, etc.. Our work can, and sometime does damage grass etc next to the new concrete. Therefore your landscaper must replace grass, irrigation, small plant, and sometimes fill dirt.
4. **WATER LINES:** We do our best to keep from breaking water lines but sometimes it happens. If the water line is your main line we will repair it and get your water on quickly. If it is an irrigation line, please have your irrigation company perform repairs and test the system just before we pour.
5. **ELECTRIC LINES:** Electric lines for landscape lighting as well as lamp posts etc. We will do our best to protect these items, but we don't know how the where laid out, or how deep they are etc. Therefore we are not responsible for these items.

Customer Initials \_\_\_\_\_ Date \_\_\_\_\_ Estimate # \_\_\_\_\_