

Dodge Turbo Air Guide (TAG) install: 2003-2004

The TAG is intended to be used with the silencer ring in place



Install the enclosed O-ring on the longer side of the support flange as shown in the photo for 2003 & 2004 trucks. The short end will be inserted into the turbo housing.



Remove the rubber boot from the turbo charger inlet and insert the TAG into the rubber boot with the O-ring facing the boot. Place one edge of the TAG into the boot with the flange of the TAG against the lip inside the boot and work the TAG in until it is seated into the boot.



The TAG should snap completely into the boot as shown .



Slip the boot back over the turbo inlet using one hand through the boot to guide the TAG into the turbo. While holding the boot firmly against the turbo tighten the clamp securing the boot to the turbo inlet. After clamping the boot

check the TAG to be sure it is secure and does not rotate by hand. If it does rotate loosen the clamp be sure the TAG is properly seated in the turbo and while pushing the boot on tighten the clamp. Reinstall the remaining air intake components. The photo above shows the 2003-2004 installation.