

Dodge Turbo Air Guide (TAG) install: 94-2002

The TAG is intended to be used with the silencer ring in place.



On 94-2002 Dodge trucks install the longer side into the turbo housing and the shorter side will be facing the inside of the intake boot.



Remove the rubber boot from the turbo charger inlet and insert the TAG into the rubber boot with the longest part of the TAG facing outward as shown. The TAG should snap into the groove inside the boot.



Place the supplied band clamp over the hose as shown in the photo below. Slip the boot back over the turbo inlet using one hand through the boot to guide the TAG into the turbo.

Note: The rubber boot will not go as far over the turbo inlet because the TAG being inserted into the hose, this will result in about a 1/4" gap from where the hose used to go on. While holding the boot carefully tighten the clamp securing the boot to the turbo inlet. After clamping the boot check the TAG to be sure it is secure and does not rotate by hand and is squarely in the turbo inlet. If it does rotate loosen the clamp be sure the TAG is properly seated in the turbo



and groove inside the air inlet boot. Snug the supplied clamp (silver colored in the photo) to secure the TAG in the groove of the hose. (DO NOT OVER TIGHTEN) Reinstall the top of the air box and tighten all clamps.