

Turbo Air Guide III  
94-2005 Dodge Cummins &  
Performance turbo installation  
instructions.



94-2002 Dodge Install

The TAG-III installs into the intake hose going into the Turbo charger inlet.

Remove the hose from the turbo  
charger and air box.

The picture to the left shows the TAG-III installation location in the inlet hose of 94-2002 Dodge Cummins. The Dodge hose has a molded groove inside which should be flush with the edge of the TAG-III as shown. For smooth hose installations the location of the TAG-III should be very similar with enough hose past the TAG-III flange to allow proper installation on the turbo.





Once the TAG-III has been located in the hose a clamp is used to secure it in place. In the picture to the left the stainless steel clamp is placed on an existing groove on the hose and tightened. The hose clamp should tighten around the flange of the TAG-III and hold it securely in place making sure the face of the flange is still inline with the groove inside the hose. Reinstall the inlet hose on the turbo charger opening and the air box and secure the hose clamps.

2003-2005 Dodge Install:



NOTE: if your truck is a 04.5 or newer, the plastic air guide must be removed from the hose.



Remove the rubber elbow from the air intake tube that connects to the turbo and position the TAG-III as shown in the photo to the left.



Then insert the TAG-III into the elbow until its flange stops against the ridge inside the hose as shown in the photo.

This photo shows the TAG-III installed in the rubber intake elbow. Reinstall the air intake hose on the turbo. You may notice that the hose does not go as far onto the turbo. This distance should be the thickness of the flange on the TAG-III or about 3/8" difference. Be certain the air intake hose is fully seated on the turbo and tighten all clamps to complete the installation.

Installation into Torque tubes and other aftermarket intake tubes.

To install a TAG-III in a smooth bore intake tube such as the Torque tube or other after market hose, generally follow the steps for the 94-2002 Dodge above.



Place the TAG-III into the smooth bore hose with the edge of the TAG-III flush with the edge of the hose as shown in the photo. Place a hose clamp around the hose so that it holds the TAG-III in place by its flange and snug the clamp. Install the hose with a second clamp similar to the installation shown above for the 94-2002 Dodge.

The TAG is so new, no claims are made for performance or mileage increases as results will vary with modifications and configuration of different vehicles. No warranty is given or implied and any damages resulting from the use of this product are strictly the responsibility of the user.